



# **Electric Water Heater**

## **OWNER'S MANUAL**

**KUUMA PRODUCTS CORPORATION**

724 WHITNEY ST.

SAN LEANDRO, CA, 94577

[www.kuumaproducts.com](http://www.kuumaproducts.com)



**If your water heater is damaged or you have questions regarding installation, performance or operation please contact Kuuma Products Customer Service at [sales@kuumaproducts.com](mailto:sales@kuumaproducts.com)**

## **INTRODUCTION**

---

Thank you for selecting a Kuuma Products electric water heater. Your unit was carefully inspected and tested at our factory. We take pride in producing one of the finest water heaters for marine use. Please take the time to read this manual carefully; many of its instructions are essential to the safe operation of your unit.

Because of the continuing refinement of our product designs, your water heater may possess features not discussed in the manual. We have tried to supply all the information you might need, so please take time to read this manual before using your water heater.

Kuuma Products advises strongly against unauthorized modification of this product, but we do encourage you to correct problems which may arise.

Please make note of the model and serial number of your water heater for future reference.

**Model #** \_\_\_\_\_ **Serial #** \_\_\_\_\_

**Any recommendation or advice by Kuuma Products Corporation, or any of its employees, is given with the understanding that it is solely as an accommodation to the customer, and should not be relied upon by the customer without an independent verification of its applicability to the customer's particular situation.**

## **IMPORTANT SAFETY INSTRUCTIONS**

---

**When using electrical appliances, basic safety precautions to reduce the risk of fire, electric shock, or injury to persons should be followed, including:**

- Read all Instructions before Operating.
- This water heater must be grounded. Connect only to properly grounded circuit.
- Install or locate this water heater only in accordance with the provided installation instructions.
- Use this water heater only for its intended use as described in this manual.
- Do not use an extension cord set with this water heater.

- Do not operate this water heater if it has a damaged power line, if it is not working properly, or if it has been damaged or dropped.
- This water heater should be serviced only by qualified service personnel. Contact nearest authorized service facility for examination, repair, or adjustment.

**WARNING:**

*This is an electrical appliance that requires a specific energy source. Each unit is manufactured to run on either 120 **OR** 240 volt circuitry. Be sure you have purchased the correct unit based on your power source.*

This heater is equipped with a heat exchanger so that the water may be heated by the coolant from your engine. This may cause the water temperature to get excessively hot unless your unit is equipped with a Temperature Control Valve which holds the temperature at approximately 140 deg F.

Do not operate this water heater if there is damage to the heater or if not performing properly. Contact Kuuma Products for assistance.

The tank and heat exchanger are aluminum. Do not use any chemicals in the heat exchanger that may cause damage to it. Use only the engine manufacturer's recommended coolant. Do not use raw water in heat exchanger circuit. Damage caused by a damaging chemical or salt reaction is not covered under warranty.

**CAUTION**

Hydrogen gas is produced in a hot water system served by this heater that has not been used for a long period of time (2 weeks or more). Hydrogen gas is extremely flammable. To reduce the risk of injury under these conditions, it is recommended that the hot water faucet be opened for several minutes at the kitchen sink before using any electrical appliance connected to the hot water system. When hydrogen is present, there will probably be an unusual sound such as air escaping through the pipe as the water begins to flow. There should be no smoking or open flame near the faucet at the time it is open.

**NOTE:** Small DC electric currents move between boat and shore through the safety ground wire in the shore cord, causing galvanic damage to your water heater. To prevent galvanic damage, this product should be used in conjunction with a galvanic isolator. These devices are inexpensive and easily installed. Galvanic corrosion is not covered by warranty.

## INSTALLATION

---

### CAUTION

*To reduce the risk of excessive pressures and temperatures in this water heater, install temperature and pressure protective equipment required by local codes and no less than a combination temperature and pressure relief valve certified by a nationally recognized testing laboratory that maintains periodic inspection of production of listed equipment or materials, as meeting the requirements for Relief Valves and Automatic Gas Shutoff Devices for Hot Water Supply Systems, ANSI Z21.22-1986. This valve must be marked with a maximum set pressure not to exceed the marked maximum working pressure of the water heater. Install the valve into an opening provided and marked for this purpose in the water heater, and orient it or provide tubing so that any discharge from the valve exits only within 6 inches above, or at any distance below, the structural floor, and does not contact any live electrical part. The discharge opening must not be blocked or reduced in size under any circumstances.) **For your convenience, this device has already been installed on your unit.***

### MOUNTING

1. If you are using the heat exchange feature, locate the water heater as close to the engine as possible. The heat exchanger port must be lower than the coolant output port of the engine.
2. Your unit is equipped with mounting brackets located either on the sides of the tank or the front and back of the tank. Use stainless steel screws to securely fasten the heater.


### PLUMBING

1. Connect cold water supply and hot water outlet to the heater as indicated on the front of the tank. (The tank is supplied with 1/2" NPT Female fitting) Force 10 recommends the installation of a check valve on the cold water inlet. Seal all pipe fittings with Teflon tape or Loctite thread sealant.

**Thermal Expansion:** When a Water Heater is installed in a closed water-supply system, such as one having a back flow preventer in the cold water supply, means shall be provided to control thermal expansion.


2. The heat exchanger inlet and the outlet is a 5/8" hose barb fitting. Connect hoses to the hose barb fitting using stainless steel hose clamps. **Warning:** Hoses **must not** contain carbon black – will void warranty.

## PLUMBING CONNECTIONS



## HEAT EXCHANGER INSTALLATION DIAGRAM

(Figure1)



3. A Temperature / Pressure relief valve (SRV) is factory installed. A drain hose should be installed to comply with ABYC standards. (*Section H-23 (23.7.4.2) in the Installation of Potable Water Systems chapter.*) Due to thermal expansion the SRV may weep slightly. This is normal operation.


## **ELECTRICAL**

1. Remove the AC wiring access cover by unscrewing the screw at the top of the cover. The bottom is held in by a tab. The tab should be between the front case and the insulation.
2. Connect the electrical supply by a qualified electrician. The electrical supply shall be armored cable or conduit per NEC code ANSI/NFPA 70-1993. *See figure 2 on page 7 for Wiring Diagrams.*

**Note: Wiring diagram is located on the inside of the removable access panel.**


3. Connect Line (Hot) to the pigtail wire coming from the High Temperature Limiter. Connect the Neutral to the unused screw terminal on the heating element marked with a white "N".
4. A strain relief should be installed in the hole on the front of the access panel to secure the AC wire.
5. Ground the water heater using the ground connection screw on the inside of the access cover. Do not use a switch in the grounding circuit.

## ELECTRICAL CONNECTIONS



## WIRING DIAGRAMS

(Figure 2)



---

**DO NOT CONNECT LINE (HOT) DIRECTLY TO THE ELEMENT**

## OPERATION

### **ELECTRIC**

When the Water Heater is operating from the AC Power, water temperature in the tank is regulated at 140 deg F (60 deg C). The thermostat is non-adjustable.

### **HEAT EXCHANGER**

When the Water Heater is operating from the Heat Exchanger, water temperature in the tank will approach the temperature of the engine coolant.

The Temperature Control Valve (TCV) regulates the flow of coolant through the Heat Exchanger by sensing the output temperature of the water in the tank. As the output water temperature rises, the thermal actuator closes the valve and restricts the coolant flow through the Heat Exchanger limiting the water temperature to approximately 140 deg F (60 deg F) . When the output water temperature cools the valve opens and allows engine coolant to flow through the heat exchanger.

## START-UP

---

1. Completely fill the tank and entire water system. Flush water through the tank to eliminate any trapped air.
2. Check all connections for leaks.
3. Apply power to the Water Heater and check to ensure the water is hot. The water will meet maximum temperature within (2) hour.

**Caution: Do not operate water heater without the heating element submerged in water.**

## MAINTENANCE

1. Disconnect AC Power prior to draining the water system.
2. Flush Tank periodically.
3. If the temperature in the tank environment is going to drop below 32 deg F (0 C), drain the tank to prevent freezing and possible damage.

## TROUBLE SHOOTING GUIDE

---

PROBLEM	CAUSE	SOLUTION
No output from the tank	Air Lock in the system	Bleed all the water lines
Water does not get hot when plugged into AC Power	High Limiter switch has tripped	Cycle AC Power
	Failed Thermostat	Replace Thermostat
	Element has burned out	Replace Element
Water Dripping from SRV	Thermal Expansion	Install Expansion tank
	Valve poppet not seated properly	Lift lever to flush valve and reset.

Model #	Capacity (gallons)	Case Material	Voltage (AC)	Heat Ex. Position	Mount Position	TCV	Overall (including mounting plate)			Dry Weight (kgs)
							Length (mm)	Width (mm)	Height (mm)	
40500	5	non ferrous	120	front	side	No	16.5"(419)	15.5"(394)	13.5(343)	30lbs(13.6)
40510	5	non ferrous	230 L1 & N	front	side	No	16.5"(419)	15.5"(394)	13.5(343)	30lbs(13.6)

40600	6	non ferrous	120	front	side	No	19.5"(495)	15.5"(394)	13.6"(346)	35lbs (15.9)
40601	6	non ferrous	120	front	front/back	No	20"(508)	13.6"(346)	13.6"(346)	35lbs (15.9)
40603	6	non ferrous	120	back	front/back	No	20"(508)	13.6"(346)	13.6"(346)	35lbs (15.9)
40610	6	non ferrous	230 L1 & N	front	side	No	19.5"(495)	15.5"(394)	13.6"(346)	35lbs (15.9)
40611	6	non ferrous	230 L1 & N	front	front/back	No	20"(508)	13.6"(346)	13.6"(346)	35lbs (15.9)
40613	6	non ferrous	230 L1 & N	back	front/back	No	20"(508)	13.6"(346)	13.6"(346)	35lbs (15.9)
40620	6	non ferrous	240 L1 & L2	front	side	No	19.5"(495)	15.5"(394)	13.6"(346)	35lbs (15.9)
40621	6	non ferrous	240 L1 & L2	front	front/back	No	20"(508)	13.6"(346)	13.6"(346)	35lbs (15.9)
40623	6	non ferrous	240 L1 & L2	back	front/back	No	20"(508)	13.6"(346)	13.6"(346)	35lbs (15.9)
41100	11	non ferrous	110/120	front	side	No	21.5"(546)	18.75"(476)	16"(406)	45lbs(20.4)
41101	11	non ferrous	110/120	front	front/back	No	22.5"(572)	16"(406)	16"(406)	45lbs(20.4)
41103	11	non ferrous	110/120	back	front/back	No	22.5"(572)	16"(406)	16"(406)	45lbs(20.4)
41110	11	non ferrous	230 L1 & N	front	side	No	21.5"(546)	18.75"(476)	16"(406)	45lbs(20.4)
41111	11	non ferrous	230 L1 & N	front	front/back	No	22.5"(572)	16"(406)	16"(406)	45lbs(20.4)
41113	11	non ferrous	230 L1 & N	back	front/back	No	22.5"(572)	16"(406)	16"(406)	45lbs(20.4)
41120	11	non ferrous	240 L1 & L2	front	side	No	21.5"(546)	18.75"(476)	16"(406)	45lbs(20.4)
41121	11	non ferrous	240 L1 & L2	front	front/back	No	22.5"(572)	16"(406)	16"(406)	45lbs(20.4)
41123	11	non ferrous	240 L1 & L2	back	front/back	No	22.5"(572)	16"(406)	16"(406)	45lbs(20.4)

41800	20	non ferrous	120	front	Vertical/Cross	No	18.75(476)	18.75(476)	29.5"(749)	55lbs(25)
41810	20	non ferrous	230 L1 & N	front	Vertical/Cross	No	18.75(476)	18.75(476)	29.5"(749)	55lbs(25)
41820	20	non ferrous	240 L1 & L2	front	Vertical/Cross	No	18.75(476)	18.75(476)	29.5"(749)	55lbs(25)

## **Limited Warranty**

---

Kuuma Products warrants the hot water tank to the original consumer to be free from defective material(s) and workmanship while under normal use and service for a period of (2) year.

During the warranty period, Kuuma Products will, at its option and without charge, repair and/or replace but not remove or re-install the faulty product.

The purchaser will return defective products to the address stated below. No product will be accepted by Kuuma Products without a Return Authorization Number. Return of defective products must be accompanied by written details of the problems and proof of purchase.

The buyer shall be responsible for shipping and insurance charges, if any, on the products returned for repair under the terms of this warranty. Kuuma Products will pay shipping of products returned to the buyer.

This limited warranty applies only to products that have been installed and used in accordance to printed instructions of Kuuma Products and does not cover improper use, vandalism, negligence or accidents.

**KUUMA PRODUCTS CORPORATION**

[www.kuumaproducts.com](http://www.kuumaproducts.com)